

Mobius Cam Instructions for loading Firmware

- Plug into comp with usb chord
- add the binary file (FWTLCAM.BIN) to the camera and turn off
- turn back on, blue blinking will start and last 20 secs the turn off
- turn on, it should be blank, add system config file (SYSCFG.TXT)
- hold power and mode at the same time to turn off. It will blink blue and then blink red a few seconds later. Now the firmware has been loaded.
- turn off and test the camera by hitting the mode button until the light appears red.
- if the photo has no red saturation, it worked!
- EMPTY the photos to the trash and then re package.